



Shower Filter Installation Instructions

1. Remove Shower Arm by turning anti-clockwise.
2. Using teflon tape provided, wrap tape in a clockwise direction 7 times around the brass thread coming out of wall.
3. Screw black plastic socket onto thread until firm. Do not over tighten or plastic will split.
4. Using teflon tape, wrap tape in a clockwise direction 7 times around the plastic thread on shower filter.
5. Replace shower arm by turning clockwise until firm and so shower head is at the right position.
6. Any troubleshooting questions please phone our toll free number on 1300 764 535